

Product Data

Castrol Careclean[®] MP

High Performance Dip And Spray Cleaner

Method Of Use

Concentration Range	2 - 5 %
Temperature Range	40 - 80°C
	(50 - 80°C in spray application)
Pressure Range	Up to 20 bar

Equipment Required

Castrol Careclean[®] MP may be used in :

- § Agitated Soaked Tanks
- § Low to Medium Pressure Batch Spray Washers
- § Low to Medium Pressure Tunnel Washers
- § Ultrasonic Cleaning Equipment
- § Intensive Flood Washers
- § Barreling Equipment
- § Mass Finishing Equipment

Typical Characteristics

Castrol	Careclean [®] MP
Appearance	Light Amber
Density @ 15°C	1.131
pH of Concentrate	9.6
pH of 2% Solution	9.4
Flash Point	None

All reasonable care has been taken to ensure that the information contained in this publication is accurate as of the date of printing. However, such information may, nevertheless, be affected by changes in the blend formulation occurring subsequent to the date of printing. Material Safety Data Sheets are available for all Castrol Industrial North America Inc. products. The MSDS must be consulted for appropriate information regarding storage, safe handling and disposal of a product.